



1. Inspect all parts and sand or file any burrs or imperfections. Be very careful as the parts are very thin and will break easy.
2. Prepare the frame for painting by washing in water with a drop of dishwashing liquid. This will remove any oil residue and allow paint to adhere properly.
3. Pre-fit all shanks and disc units before gluing to ensure proper fit when attaching to frame bars. May need to file or sand for proper fit.
4. As shown in the diagram, front disc assembly is mounted on the front frame rail, the shanks on the rear bar.
5. Drill out the holes for axles/pins with a .025 drill bit
6. Mount tires on rims. May need to sand for proper fit.
7. Slide pin through rim, cut off excess, apply glue to end of pin and insert into drilled hole.